

---

## AFT Sealant Application:

---

1. Insert a dam of crumpled paper, foam strip pieces, or White Oakum about 6 inches into the conduit.
2. Shake can for 60 seconds to mix.
3. Lift hinge and insert dispensing nozzle into top orifices so that the arrow lines up with the dispensing nozzle.
4. Invert aerosol can. Insert nozzle all the way into the seal space and fully squeeze the hinge to spray sealant into the conduit between cables.

***It is important to hold the can upside down and fully depress the hinge to spray. The foam should be a uniform color.***

*Fill chart for 6-inch plug depth:*

Conduit size	Fill time	Seals per can
2 inch conduit	2 Sec	15 seals
4 inch conduit	7 Sec	5 seals
5 inch conduit	11 Sec	3 seals
6 inch conduit	16 Sec	2 seals
8 inch conduit	28 Sec	1 seals

5. Fill conduit three-fourths full. Place an additional dam on the outside of the conduit or hold with gloved hands to prevent the expanding foam from escaping from the conduit for 2 to 3 minutes.